INSTRUCTIONS

CONTACT LENS POLISHER

- 1. Install the **flat** foam insert into polisher head.
- 2. Put polish on the foam insert.
- 3. Place the contact lens **convex** side up on the tip of your index finger.
- 4. Hold the polisher in your other hand and place the polisher head over the contact lens on your finger.
- 5. Turn on the polisher by pressing the plastic clip against the metal body.
- 6. Control the speed by increasing or decreasing the pressure on your finger. The harder you push the slower the motor spins and the more aggressive the polishing becomes.

Change inserts to polish the concave side.

- 1. Install the **cone** foam insert into polisher head.
- 2. Put polish on the foam insert.
- 3. Place the contact lens **concave** side up on the tip of your index finger.

Repeat steps 4 to 6.

Battery Replacement:

Slide cover off the bottom to replace both AA batteries.



225 Cadwalader Avenue, Elkins Park, PA 19027
(800) 659-2250 Fax (215) 884-0418 e-mail: info@guldenophthalmics.com

www.guldenophthalmics.com

Rev. 9/22/08

CONTACT LENS POLISHER

- 1. Install the **flat** foam insert into polisher head.
- 2. Put polish on the foam insert.
- 3. Place the contact lens **convex** side up on the tip of your index finger.
- 4. Hold the polisher in your other hand and place the polisher head over the contact lens on your finger.
- 5. Turn on the polisher by pressing the plastic clip against the metal body.
- 6. Control the speed by increasing or decreasing the pressure on your finger. The harder you push the slower the motor spins and the more aggressive the polishing becomes.

Change inserts to polish the concave side.

- 1. Install the **cone** foam insert into polisher head.
- 2. Put polish on the foam insert.
- 3. Place the contact lens **concave** side up on the tip of your index finger.

Repeat steps 4 to 6.

Battery Replacement:

Slide cover off the bottom to replace both AA batteries.

GuldenOphthalmics